SP6000/MG5050

Key / LED Lit	Main Menu Trouble	Key / LED Lit	Sub-Menu Trouble
[1]	Wireless Zone Low battery	[1] - [32]	Zone in Low Battery
[2]	Power Trouble	[1]	Low/No Panel Battery
		[2]	AC Fail on Panel
		[3]	Aux Failure
		[4] - [10]	Mark in Access for Tech
[3]	Bell Trouble	[1]	Bell Disconnected
		[2]	Bell Overload
[4]	Communication Trouble	[1]	Telephone Line Monitor
		[2] - [10]	Mark in Access for Tech
[5]	Tamper Trouble	[1] - [32]	Zone in Tamper Trouble
		[STAY]	Panel in Tamper Trouble
[6]	Module Tamper Trouble	[1] - [10]	Mark in Access for Tech
[7]	Fire Loop Trouble	[1] - [32]	Zone in Fire Loop Trouble
[8]	Timer Loss	-	-
[9]	Wireless Zone Supervision	[1] - [32]	Zone in Supervision Loss
		[STAY]	RF Jamming
[0]	Module Supervision Loss	[1] - [10]	Mark in Access for Tech
[16] or [SLEEP]	Keypad Fault	-	-

Timer Reset

-Press [TBL] followed by [8]
-Enter time in [HH:MM] format
-Select format [1] = 24HR, [2] = AM, [3] = PM
-Enter date in [YYYY/MM/DD] format
-Press [CLEAR] to exit

Bypass

-Enter Bypass by pressing [BYP] followed by master code
-Select which zones to bypass, press [ENTER] once finished to confirm

Add/Remove Users

1) Press [⏻] followed by master code
2) Enter 2-digit user slot (01-32)
3) Enter 4 digit code
4) Enter code again, followed by [ENTER]
5) (User slots 02 or greater) If system is partitioned, press [1] and/or [2] to assign partitions, followed by [ENTER]
6) [CLEAR] to exit

-To remove code (slots [02] or greater), repeat steps 1 - 3
-Press and hold [SLEEP] until confirmation beep
-[CLEAR] to exit