SPECTRA

Key / LED Lit	Trouble Type
[1]	No/Low Panel Battery
[2]	Wireless Low Battery
[3]	AC Power Failure
[4]	Bell Disconnected
[5]	Bell Overload
[6]	Aux Overload
[7]	Monitoring Communication Trouble
[8]	Timer Loss
[9]	Tamper Trouble
[0]	Telephone Line Monitoring
[STAY] or [11]	Fire Loop Trouble
[FORCE] or [16]	Keypad Fault
[BYP] or [12]	Module Loss
[MEM] or [13]	Wireless Supervision Loss

Timer Reset

-Press [TBL] followed by [8]
-Enter time in 24HR format [HH:MM]
-Press [CLEAR] to exit

Bypass

-Enter Bypass by pressing [BYP] followed by master code
-Select which zones to bypass, press [ENTER] once finished to confirm

Add/Remove Users

1) Press [ENTER] followed by master code
2) Enter 3-digit user slot (Master code being [001] and additional users starting at [004]
3) Enter 4 digit code, followed by [CLEAR] to exit

-To remove code (slots [004] or greater), repeat steps 1 & 2
-If the user slot is in use, a number key will be lit, pressing the keys in order will reveal the code in that slot
-If the desired code to be removed is found, re-enter the user slot. If not, repeat step 2 with a different user slot
-Press [FORCE] four times to clear code, keypad will emit confirmation beep